



INSTALL OVERVIEW – ATTACTMENT

Start with #080050-3. There is only one of these. Remove the bearing stud assembly from base and then install roller sleeve and reinstall.

Move to #080050-2 next. There are 3 of these. These are mounted next to the cross braces. Last to install are the remaining 8 of #080050-1.

